


Remote Control  
(MF-100 no remote control)



- 1** Power On/Off
- 2** Mute
- 3 11** Volume control
- 4** Short press to switch to clock mode.  
Long press to set time, press again to finish clock set up.
- 5** Short press to switch mode between Radio -> USB -> SD -> Bluetooth.  
USB/SD only available when inserted.  
End phone call when press under Bluetooth.
- 6 8** Same function as **⏮ / ⏭**
- 7** Confirm key, Radio/MP3 volume control, EQ selection.
- 9** Under Bluetooth, press to answer phone call.  
Under Radio, press to switch between FM1/FM2/FM3/AM1/AM2.
- 10** Press to select song under MP3 mode.
- 12** Under Bluetooth, press to delete dial number.
- 13 24** Number keys